




## Screen Up Wall Mount - Rear Fix Channel

### Screen Up / Screen Up Wall Mount

- Quick and easy with a professional look
- A better way to build your own privacy screens
- Long-life aluminium



## A BETTER WAY TO BUILD PRIVACY SCREENS

Whites Screen Up Wall Mount captures the natural beauty of timber with professional looking results. This easy to install screening system is made from a strong and durable aluminium channel and allows you to choose any colour or type of slats you prefer, to make a quick and professional looking screen for your home or office. The channels fix directly to existing walls and posts. Available in Black.

Each pack comes with step-by-step assembly instructions and contains:

- Wall-Mount Channel (x1)
- 20mm Spacers (x22 for 2m OR x12 for 1.1m)
- End Caps (x2)
- "L" Bracket (x1)

As a general guide, the 2m post will hold 18 slats @ 90mm width or 22 slats @ 70mm width; the 1.1m post will hold 10 slats @ 90mm width or 12 slats @ 70mm width.

Code	Product Description	Channel Length
16910	Screen Up Wall Mount - 16mm Rear Fix	1100mm
16912	Screen Up Wall Mount - 16mm Rear Fix	1975mm
16914	Screen Up Wall Mount - 19mm Rear Fix	1100mm
16916	Screen Up Wall Mount - 19mm Rear Fix	1975mm

### Handy Hints:

- For greater privacy, or the slimline look, use [Screen Up Slimline Spacers \(16871\)](#) that provide a 10mm gap between slats (regular gap 20mm).
- Button head screws (15mm) are recommended for channels and "L" brackets.
- Use with [Screen Up Freestanding](#) to extend your screen beyond existing walls and posts. Both freestanding and wall-mount systems fit together perfectly to create an integrated privacy screen.